

		8	7		6		5	+	4		3		2			EMICIONIC.	
	EQUIPMENT LIST REF		EQUIPMENT LIST REF			EQUIPMENT L						ZONE REV ALL REVIS	DESCRIPT SIONS LISTED		DATE APPROVED		
$\ \ H \ _{\underline{D}}^{R}$	REFERENCE DESIGNATION	DESCRIPTION	SHEET LOCATION NUMBER	REFERENCE DESIGNATION	DESCRIPTION	SHEET NUMBER	LOCATION	REFERENCE DESIGNATION	DESCRIPTION	SHEET NUMBER	LOCATION			— – INITIAL RI –PRODUC ERR SSS	CT BASELINE-		— — H
	A1 A2 A3	FLASHER UNIT CENTRAL TIRE INFLATION SYS DIMMER MODULE CAB RADIO (GFE)	8 213 STEM ECU 14 490 6 125	DS56 DS57 DS58	FRONT TOP (ID) RIGHT AMBER FRONT RIGHT UPPER AMBER FRONT LEFT UPPER AMBER FRONT RIGHT LOWER AMBER	9 9	256 257 258	E84 E85 E86	SPLICE SPLICE SPLICE SPLICE	20	232 777 777			B8 B 1)DS27 DI B8 2)DS28 DI	ESCRIPTION CH	OW AIR WAS FRO	M WAS REAR BRAKE AIR ONT BRAKE AIR
	A5 A7 A8	CTIS PNEUMATIC CONTROL UI ENGINE ECM ABS ECU	NIT 14 494 12 402 7 147	DS60 DS61 DS62	FRONT LEFT LOWER AMBER RIGHT DOOR MARKER AMBER LEFT DOOR MARKER AMBER	9 9	262 260 263	E88 E89 E90	SPLICE SPLICE	11 6 20	372 146 778			B5	LICE ADDED SI DS116 BATTER SCRIPTION 200	HEET 6 & 136 Y DISCONNECT D AMP LOAD &	BATT. CNTRL DEVICE
	A10 A11 A12	ELECTRONIC CONTROL UNIT GEAR SELECTOR	4,5,10,6 49,78,309,146 5 93	DS63 DS64 DS65	WORK LIGHTS ON/OFF BLACK OUT OVERRIDE LEFT SIDE REAR MARKER RED	6 6 10	116 117 283	E91 E92 E93	SPLICE SPLICE SPLICE SPLICE	20 20 3	778 778 778 30			ERR SSS—	U5788	AND E95	D.FRISS 02-03-06 ADJ SEH
	A13 A18 A19	TRANSMISSION CONNECTOR INDICATOR PANEL ARCTIC KIT ECU FUEL WATER SEPARATOR	5 84 6 127 11,19 350,768	DS66 DS67 DS68	RIGHT SIDE REAR MARKER RED	10 10 10	284 285 286	E94 E95 F	SPLICE SPLICE DOOR AJAR FLASHER	3 3 13	17 32 456			REVISED IA	AW R2 CHANG DERER WAS M		PLCS) L.RODNEY 02-07-11 LJR SEH
	AZ I	ARCTIC KIT HEATER PUMP MO	5 25 6 112 OTOR 11 350	DS69 DS70 DS71 DS72	RIGHT REAR/REAR MARKER RED REAR (ID) LEFT RED REAR (ID) MIDDLE RED REAR (ID) RIGHT	10	287 288 289	F1 F2 F3	FUSE FUSE FUSELINK FML WASHED DIME	19 13 12	755 462 420 721			D8 D 2) ADDED A4 3) DISTRIE	CB85 TO LIST BUTION STATEM	MENT C: WAS A	
	B1 B2 B3	ARCTIC KIT HEATER MOTOR STARTER MOTOR WIPER MOTOR WASHER MOTOR	3 29 18 720 18 722	DS73 DS74 DS75	REAR COMPOSITE MARKER LEFT REAR COMPOSITE MARKER RIGHT HEADLIGHT RIGHT INTERIOR LIGHT	10 10 9 1.3	290 291 238 474	FL1 FL2 FL3 G1	EMI WASHER PUMP EMI WIPER MOTOR EMI HEATER MOTOR ALTERNATOR 100 AMP	18 8	721 721 188			D3 4) MOVE ERR SSS-		FROM ZONE B	4 TO D3 L.RODNEY 02-09-18 ADJ SEH
	B4 B6,B6A B9	HEATER MOTOR AUXILIARY OIL COOLER FAN MOTOR SWING FIRE PUMP MOTOR	11 379	DS76 DS77 DS78	INTERIOR LIGHT INTERIOR LIGHT CHECK TRANSMISSION INTERIOR LIGHT	13 6 13	474 139 472	G2 KS K1	ALTERNATOR 200 AMP AUXILIARY STARTER SOLENOID 24V IGNITION RELAY	18 3 3	727 30 22						
	B10 B11 B12	TRANSFER CASE CONNECTOR VAN FAN MOTOR SWING FIRE HEATER	11 378	DS79 DS80 DS81	INTERIOR LIGHT INTERIOR LIGHT INTERIOR LIGHT	13 13 13	472 472 482	K2 K4 K5	12V IGNITION RELAY SPARE RELAY WIPER RELAY	3 14 18	22 506 706						
	BT1 BT2 BT3	BATTERY BATTERY BATTERY BATTERY	3,18 9,732 3,18 9,732 3,18 11,732 3,18 11,732	DS82 DS83 DS84	INTERIOR LIGHT INTERIOR LIGHT EXTERIOR MARKER LIGHT	13 13 13	482 482 482	K6 K7 K8	(NOT USED) HEADLIGHT RELAY LOW/HIGH BEAM RELAY	9	237 237						
	CB1 CB2 CB3	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	13 451 13 451	DS86 DS87	EXTERIOR MARKER LIGHT EXTERIOR MARKER LIGHT EXTERIOR MARKER LIGHT EXTERIOR MARKER LIGHT	13 13 13	467 467 467	K9 K10 K11 K12	HAZARD FLASHER RELAY STOP/LIGHT RELAY EXCITATION RELAY WORK LIGHT RELAY	8 8 3	198 198 36						
	CB4 CB5 CB7	CIRCUIT BREAKER	13 454 13 454 13 454	DS89 DS90 DS91	EXTERIOR MARKER LIGHT EXTERIOR MARKER LIGHT EXTERIOR MARKER LIGHT	13 13 13	467 469 469	K13 K15 K16	ROTARY WARNING RELAY AUXILIARY COOLER RELAY EXHAUST BRAKE RELAY	9 4 12	233 40 427						
	CB8 CB9 CB10	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	13 454 13 454 13 461	DS92 DS93 DS94	EXTERIOR MARKER LIGHT FXTERIOR MARKER LIGHT	13 13 13	469 469 469	K17 K19 K20	ABS LAMP RELAY START INHIBIT RELAY MARKER LAMPS RELAY	7 12 9	176 429 262						F
	CB12 CB13	CIRCUIT BREAKER (NOT USEI	7)	DS95 DS96 DS97	EXTERIOR MARKER LIGHT EXTERIOR MARKER LIGHT ARCTIC TROOP HEATER SWING FIRE	13 6 6	469 118 119	K21 K22 K24	REAR LEFT LIGHT RELAY REAR RIGHT RELAY (NOT USED)	8 8	204 208						
	CB14 CB15 CB16	CIRCUIT BREAKER (NOT USEL CIRCUIT BREAKER (NOT USEL CIRCUIT BREAKER (NOT USEL CIRCUIT BREAKER (NOT USEL	D) D)	DS98 DS99 DS100	TAILGATE RELEASE DUMP BODY UP/DOWN FUEL PREHEAT HEATER	6 6	120 121 122	K25 K26 K27	REVERSE WARNING RELAY NEUTRAL START RELAY TRAILER B.O. STOP LIGHT RELAY TRAILER B.O. STOP LIGHT RELAY	4 3 14	66 36 523						
	CB18 CB19 CB20	CIRCUIT BREAKER (NOT USED CIRCUIT BREAKER	5) 5 75	DS101 DS102 DS103 DS104	PORTABLE WORK RIGHT HAND PORTABLE WORK RIGHT HAND PORTABLE WORK LEFT HAND	10 10 10	295 296 297	K28 K29 K30 K31	TRAILER MARKER LIGHT RELAY TRAILER B.O. MARK LIGHT RELAY TRAILER REAR LEFT LIGHT RELAY TRAILER REAR RIGHT LIGHT RELAY	9 14 8 8	519 202 207						
	CB21 CB22 CB23	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER (NOT USEE CIRCUIT BREAKER	3 28 12 424 8 188	DS105 DS106 DS107	PORTABLE WORK LEFT HAND PORTABLE WORK RIGHT HAND PORTABLE WORK LEFT HAND	10 10 10	298 299 300	K32 K33 K34	(NOT USED) (NOT USED) DIFFERENTIAL LOCK RELAY	3	30						
	CB30 CB35 CB36	CIRCUIT BREAKER CIRCUIT BREAKER (NOT USED CIRCUIT BREAKER (NOT USED	10 306 D)	DS108 DS110 DS111	LAMP TEST (NOT USED) (NOT USED)	6 6 6	125 137 138	K35 K36 K37	POWER CONTROL RELAY BLACKOUT OVERRIDE RELAY PTO RELAY (NOT USED)	13 13 4	464 464 64						
	CB37 CB38 CB39 CB40	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	9 232 14 519 14 505	DS112 DS113 DS114	FAST IDLE WARM UP/ EXHAUST BRAKE INLET AIR HEARTER ABS	6	112 112 129	K40 K41 K42	VAN LIGHT RELAY ENGINE PTO RELAY RADIO POWER RELAY	13 12	464 429						E
	CB41 CB42 CB43	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	9 260 12 425 4 61	DS116 E2 E3	BATTERY DISCONNECT SPLICE SPLICE	6 11 8	133 356 204	K53 L1 L2 L3	FAN SOLENOID FUEL SOLENOID PTO SOLENOID	4 4 4	73 39 68 69						
	CB44 CB45 CB48	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	8 201 3 28,364 11 360	E4 E5 E6	SPLICE SPLICE SPLICE SPLICE	8 7 20	207 174 784	L4 L5 L6	WINCH IN SOLENOID WINCH OUT SOLENOID INTER-AXLE DIFFERENTIAL SOLENOID	4 4 3	70 70 34			CM A. 1-29-	PPROVE 04	ED	
	CB49 CB50 CB53	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	4 61 11 365 11 363	E7 E8 E9	SPLICE SPLICE SPLICE SPLICE	12 20 20	425 790 790	L7 L8 L9	TAILGATE RELEASE SOLENOID DUMP BODY UP SOLENOID DUMP BODY DOWN SOLENOID	11 11 11	376 376 377				ECP7385 JMENT	5R1	—
	CB54 CB65 CB66	CIRCUIT BREAKER	9 251 9 245 14 519 9 264	E10 E11 E12	SPLICE SPLICE SPLICE SPLICE	12 9 14	403 265 514	L10 L11 L15	INLET AIR HEATER SOLENOID ENGINE EXHAUST BRAKE SOLENOID ETHER STARTER SOLENOID ARCTIC KIT RECIRCULATING SOLENOID	12 12 4	421 433 44 373			DOC			
	CB68 CB70 CB71	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	4 39 8 199 8 196	E15 E16 E17	SPLICE SPLICE SPLICE SPLICE SPLICE SPLICE	10 10 10	288 283 285	L17 LS1 LS2	ARCTIC KIT SOLENOID HORN AUDIBLE ALARM	11 18 7	370 717 181		EQUIPMENT	T LIST REF			
	CB73 CB74	CIRCUIT BREAKER CIRCUIT BREAKER	10 295 4 64 8 199	E18 E19 E20	SPLICE SPLICE SPLICE	8 9 10	195 249 291	M2 M3 M4	VOLTMETER ENGINE OIL PRESSURE METER AIR PRESSURE FRONT METER	3 3 3	7 5 4	REFERENCE	DESCRIPTION		SHEET	LOCATION	D
	CB76 CB77 CB78	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER (AUTO RES CIRCUIT BREAKER CIRCUIT BREAKER	8 192 3,7 29,179 SET) 9 236	E21 E22 F23	SPLICE SPLICE	14,8,9,10 219 9	1,195,202 9,249,288 259	M5 M6 M7	AIR PRESSURE REAR METER WATER TEMPERATURE METER FUEL LEVEL METER	3 3	2 1	DESIGNATION S24	PARKING BRAKE SWITCH	ľ	NUMBER	1.40	
	CB80 CB82 CB83	CIRCUIT BREAKER CIRCUIT BREAKER CIRCUIT BREAKER	9 264 7 172 7 173	E24 E25 E26	SPLICE SPLICE SPLICE SPLICE	9 9 14	258 261 514	M9 M42 M43	SPEEDOMETER (NOT USED) CHEMICAL ÁLARM (GFE) CHEMICAL DETECTOR (GFE)	10	304 364	S26 S27 S28	DUMP UP INDICATOR WATER TEMPERATURE SWITCH OIL PRESSURE SWITCH OIL LEVEL SENSOR SWITCH (1)	NOT USED)	6 3	142 131 36	
	CB85 DS1 DS2	FUEL GAUGE ILLUMINATION WATER GAUGE ILLUMINATION	9 239 6 112 6 113	E27 E28	SPLICE SPLICE	10 14,8,9,10 513 219	288 1,195,202 9,249,288	MT3 MT4 MT5	ENGINE OIL PRESSURE SENSOR AIR PRESSURE FRONT SENSOR AIR PRESSURE REAR SENSOR	3 3 3	5 4 3	S29 S31 S32			6 11 13	136 356 471	
	DS3 DS4 DS5	AIR FRONT GAUGE ILLUMINATION AIR REAR GAUGE ILLUMINATION OIL PRESSURE GAUGE GAUG	DN 6 115	E29 E30 E31	SPLICE SPLICE SPLICE SPLICE	14 8 9	513 195 249 290	MT6 MT7 MT9	WATER TEMPERATURE SENSOR FUEL LEVEL SENSOR (NOT USED) CTIS PRESSURE TRANSDUCER ABS RIGHT FRONT WHEEL SENSOR	3 3	1	S33 S34 S35	ARCTIC KIT OPTION SWITCH INTERIOR SWITCH INTERIOR BLACKOUT SWITCH FORWARD A.C. OUTLETS SWITCH FAN MOTOR SWITCH TAILGATE RELEASE SWITCH DUMP BODY UP/DOWN SWITC		13 13 13	463 470 453	
	DS7 DS8 DS9	SPEEDOMETER ILLUMINATION VOLTMETER ILLUMINATION FAN OFF DUMP UP INDICATOR	6 119 6 120 6 142	E32 E33 E34 E35	SPLICE SPLICE	10 10 10 14	296 295 516	MT11 MT12 MT13	ABS LEFT REAR WHEEL SENSOR ABS LEFT REAR WHEEL SENSOR	7 7	491 150 151	\$36 \$37 \$40	DUMP BODY UP/DOWN SWITC CHARGE AIR TEMPERATURE SV TROOP ALARM SWITCH	CH WITCH (ETHER)	11 11 4	376 377 44 182	
	DS10 DS11 DS12	ROTATING WARNING ETHER START HAZARD WARNING	6 122 6 123 6 123	E36 E37 E38	SPLICE SPLICE SPLICE SPLICE SPLICE SPLICE	14 14 8	510 518 204	MT15 MV1 MV2	ABS RIGHT REAR WHEEL SENSOR ABS RIGHT FRONT MODULATOR VALVE ABS LEFT FRONT MODULATOR VALVE	7 7 7	156 147 148	\$48 \$56 \$5/1	LAMP TEST SWITCH (NOT USED) IGNITION SWITCH		7	177	С
	DS13 DS14 DS15	IGNITION LEFT TURN RIGHT TURN	6 124 6 146 6 145	E39 E40 E41	SPLICE SPLICE	8 8 10	193 197 288	MV3 MV4 PDP	ABS RIGHT REAR MODULATOR VAVLE ABS LEFT REAR MODULATOR VALVE POWER DISTRIBUTION PANEL	7 7	158 159	S5/2 S5/5 S5/6	ROTATING WARNING LIGHT		9 10 4	244 301 58	
	DS17 DS18	HIGH BEAM HEATER SWITCH ILLUMINATION CTIS ON/OFF ILLUMINATION ENGINE FAN OFF	6 146 N 8 186 6 112	E42 E43 E44 E45	SPLICE SPLICE SPLICE SPLICE	10 14 10 8	291 511 285 207	PP1 PP2 R1 R2	200 AMP LOAD & BATT. CNTRL DEVICE 200 AMP POLARITY PROTECTION AIR DRYER (NOT USED)	18 3 3	14 734 35	S5/8 S5/9 S5/10	PTO ON/OFF SWITCH BLACKOUT OVERRIDE SWITCH FUEL PREHEAT SWITCH CTIS ON/OFF SWITCH		10 11 14	299 381 502 39,132	
	DS20 DS21 DS22	VAN DOOR CHECK ENGINE PARKING BRAKE	6 127 6 138 6 131 6 134	E45 E46 E47 E48	SPLICE SPLICE	8 9 10	195 249 291	R3 R4 R5	(NOT USED) FUEL PREHEAT ELEMENT (OPT) (NOT USED) (NOT USED)	11	383	S5/11 S5/14 S5/15 S5/16	ENGINE FAN OFF SWITCH WINCH ON/OFF SWITCH WINCH IN/OUT SWITCH ETHER STARTER SWITCH		4,0 4 4 4	39,132 70 70 44	
	DS24 DS25	PTO ON LOW OIL PRESSURE WATER TEMPERATURE	6 132 6 127 6 131	E49 E50 E51	SPLICE SPLICE SPLICE SPLICE SPLICE	10 10 10	288 288 283	R6 R12 S3	(NOT USED) (NOT USED) TERMINATING RESISTOR STEERING COLUMN SWITCH	7 8,9,18	163 216,240,705	S5/22 S5/25 S5/26	FULL HAZARD WARNING SWITC SWING FIRE PUMP SWITCH FAST IDLE SWITCH		8 11 12	203 379 405	
	DS26 DS27 DS28	EXHUAST BRAKE CHARGING SYSTEM LOW AIR	6 144 6 136 6 137	E52 E53 E54	SPLICE SPLICE SPLICE	10 10 10	285 296 297	S4 S6 S8	MAIN LIGHT SWITCH STARTER PUSHBUTTON TRAILER STOPLIGHT SWITCH	8,9 3 8	194,240 32 190	S5/27 X10	EXHAUST BRAKE/WARM UP S' ENGINE BLOCK INLET AIR HEATER DIAGNOSTIC CONNECTOR	WITCH	12 12 12	434 414 421	
	DS30 DS31	CTIS OFF STOP ENGINE WINCH ON-OFF CHEMICAL DETECTOR	6 135 6 128 6 113 6 142	E55 E56 E57 F58	SPLICE SPLICE SPLICE SPLICE SPLICE SPLICE SPLICE SPLICE	10 14 14	296 519 514 289,297,512	\$10 \$11 \$12 \$13	STOPLIGHT SWITCH BLACKOUT OVERRIDE WINDOW SWITCH BLACKOUT OVERRIDE WINDOW SWITCH BLACKOUT OVERRIDE WINDOW SWITCH BLACKOUT OVERRIDE WINDOW SWITCH	13 13	495 465 465	l S57 l	DIAGNOSTIC CONNECTOR MASTER BATTERY DISCONNECT OUTSIDE IGNITION SWITCH OUTSIDE BATTERY DISCONNECT	T SWITCH	20 3 3	787 23 21	B
	DS35 I	CHEMICAL DETECTOR SIDE MARKER LIGHT CTIS OVERSPEED BLACKOUT STOP	10 281 6 143 8 195	E59 E64 E65	SPLICE SPLICE SPLICE SPLICE SPLICE SPLICE	8,10 196,1 10 9	197,291,295 288 248	S14 S15 S16	BLACKOUT OVERRIDE WINDOW SWITCH BLACKOUT OVERRIDE WINDOW SWITCH (NOT USED)	13	466 466	S60 K54 K55	OUTSIDE BATTERT DISCONNECT OUTSIDE STARTER SWITCH BATTERY DISCONNECT RELAY BATTERY DISCONNECT RELAY		3 3	32 22 22	
	DS36 DS37	BLACKOUT STOP LEFT COMPOSITE LAMP	8 196 8 203 8 206	E66 E67 E68	SPLICE SPLICE	9 9 9	245 236 237	S17A S17B S18	BLACKOUT OVERRIDE WINDOW SWITCH (NOT USED) DOOR SWITCH DOOR AJAR SWITCH PTO ON SWITCH	6 6 14	132 137 511			I	I		
	DS39 DS40 DS41	RIGHT COMPOSITE LAMP FRONT LEFT TURN SIGNAL SIDE MARKER LIGHT TRANSMISSION TEMPERATURE	8 209 10 282 6 139	E69 E70 E71	SPLICE SPLICE SPLICE	10 4 6	299 42 136 5 196 202	S20 S23 DISTRIBUTIO	FRONT AIR SWITCH CTIS AIR PRESSURE SWITCH ON STATEMENT C:	6	134						
	DS42 DS43	FRONT RIGHT TURN SIGNAL WINCH IN/OUT HEADLIGHT LEFT	8 214 6 114 9 235 8 219	E72 E73	SPLICE SPLICE	6,10,14 206,2 6,10,11 1	5,196,202, 219,291,512 37,304, 367,379	DISTRIBUTION AGENCIES AREASON:	ON AUTHORIZED TO U.S. GOVERNMENT AND THEIR CONTRACTORS. ADMINISTRATIVE OR OPERATIONAL USE	MECHAI			UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MILLIMETERS TOLERANCES ON CONTRACTOR	7-99-C-S030	U.S. ARMY WARR	, TANK AUTOI EN, MICHIGAN	MOTIVE COMMAND 48397-5000
	DS46	BACKUP LIGHT PTO ON/OFF PARKING LIGHT LEFT PARKING LIGHT RIGHT	6 115 9 245 9 246	E74 E79 E80	SPLICE SPLICE SPLICE	4,11 42 9 9	2,372,381 232 232	DATE OF D OTHER REC REFERRED	ETERMINATION: 02-09-18 QUESTS FOR THIS DOCUMENT SHALL E TO THE U.S. ARMY TANK AUTOMOTIVE	YP TS EL2			1 PLACE 2 PLACE STEWART	& STEVENSON SERVICES Y TEXAS U.S.A. DATE (YR-MO-DA)			
	DS49 DS50 DS51	BLACKOUT MARKER FRONT BLACKOUT MARKER FRONT BLACKOUT MARKER REAR	9 247 9 248 9 249	E81 E82 E83	SPLICE SPLICE SPLICE	6,7 1 9 9	131,181 232 232	AND ARMAN WARREN, M	MENTS COMMAND, ATTN: SFAE—CSS—M MCHIGAN 48397—5000	Т.			A.JOINE CHECKER S.E.HAL	ER 02-02-27 ENGINEER	SIZE CAGE CODE	·	LECTRICAL A
	DS52 DS53 DS54	BLACKOUT MARKER REAR BLACKOUT DRIVE LIGHT FRONT TOP (ID) LEFT AMBER	9 251 9 253 R 9 254			<u> </u>		DOCUMENT:	ON NOTICE: FOR UNCLASSIFIED, LIMITE S DESTROY BY ANY METHOD THAT WIL DISCLOSURE OF CONTENTS OR		NEXT ASS	Y USED ON	DRAWING AP 2.FIESTER J. QUA AT'L ENGR DESIGN APP	PPROVAL - GOV'T ADERER PROVAL - GOV'T	E 1920	7 12	2422872
	DS55	FRONT TOP (ID) MIDDLE AME	BER 9 255					RECONSTRU	JCTION OF THE DOCUMENT.		APF	PLICATION	J. QUA	ADERER	FILE NAME 1755		TACOM-E-METRIC
		Ŏ			<u> </u>		5		4				2				



































